

ADS states

“ADS Off” means the ADS is not performing any activity.

“ADS On” means either an ADS feature is performing the DDT or the system is in ADS Standby.

“ADS Standby” means no ADS feature is performing the DDT, however the ADS may be performing some other activity (e.g. determining whether the vehicle is in the ODD).

“ADS Feature Active” means an ADS Feature is performing the DDT.

“Activation” means the act of changing the operational state of the ADS feature, from the state in which it is performing none of the DDT to the state in which it is performing all of the DDT.

“Deactivation” means the act of changing the operational state of the ADS feature, from the state in which it is performing all of the DDT to the state in which it is performing none of the DDT. This could be a user-initiated deactivation to manual driving, a system-initiated deactivation to manual driving or the system returning to ADS Standby whilst the vehicle is stopped.

Optional

“Switching On” means the act of changing the status from ADS Off to ADS Standby.

“Switching Off” means the act of changing the status from ADS Standby to ADS Off.

Is a term needed for switching from one feature to another?

