

ITEMS		Monitored by self-test function ?
Components	Failure type	
AECD Control Unit	Internal failure	yes
External Mobile network communication device	Electrical connection	yes
External GNSS receiver	Electrical connection	yes
External Mobile network communication antenna	Electrical connection	yes
External GNSS antenna	Electrical connection	yes
Crash Control Unit	Electrical connection	yes
Power supply	Electrical connection	yes
Loudspeaker	Electrical connection	yes/no
Microphone	Electrical connection	yes/no
Manual call button	Electrical connection	yes/no
Status indicator	Electrical connection	yes/no
SIM	not present	yes/no
No communication failures	???	yes/no
State of Health of dedicated battery	???	yes/no

**If the above listed components are combined and not detachable, they should I**

<b>If no : technical reasons prohibitive of monitoring</b>
Not Applicable
Not Applicable
Not Applicable
Not Applicable
Not Applicable
Not Applicable
Not Applicable

**be considered as one component.**

Comments
Internal failure = e.g. hardware failure, watch-dog, software checksum, software image integrity, ...
e.g. crash detection sensor system, triggering device, ...
(in table 1 : dedicated battery is connected)