

BRAKE DUST MEASUREMENTS-HORIBA APPROACH

TF2

05.10.2017, Dr. D.Lugovyy

HORIBA


© 2016 HORIBA, Ltd. All rights reserved

Agenda

1	Project Definition
2	Comparison of existing sampling concepts
3	Horiba-AUDI concept
4	Role of volatile content and comparison of measurements techniques
5	Findings
6	Outlook

Project definition

To be solved




Aim of the project

Developing new particle measuring principle for analysis of Brake
Dust pollutions

Comparison of existing sampling systems

Sampling of Brake Dust- Biggest Challenge for Particulate Matter measurements


Hose




Sampling Box



Environmental chamber



Exhaust duct



Pro


- ✓ Easy to install
- ✓ Different sampling points are possible

Contra

- Reproducibility of results
- Calculation PN per km
- High level of background particle concentration
- Probe homogeneity

Sampling of Brake Dust

Hose




Pro

- ✓ Easy to install
- ✓ Different sampling points are possible


Contra

- Reproducibility of results
- Calculation PN per km
- High level of background particle concentration
- Probe homogeneity


Sampling Box



Environmental chamber




Exhaust duct



Horiba focus

Sampling of Brake Dust

Hose



Pro

- ✓ Easy to install
- ✓ Different sampling points are possible

Contra

- Reproducibility of results
- Calculation PN per km
- High level of background particle concentration
- Probe homogeneity

Sampling Box




Pro

- ✓ Easy to install
- ✓ Reproducibility of results
- ✓ Fast response on emissions events
- ✓ Reduction of background particle concentration level
- ✓ Possibility to use for RDE

Contra

- Probe homogeneity
- Calculation PN per km
- Limited number of applications

Environmental chamber




Pro

- ✓ Calculation PN per km
- ✓ Reproducibility of results
- ✓ Reduction of background particle concentration level

Contra

- Complicated installation
- Limited number of applications
- Probe homogeneity
- Emissions response is averaged over time and volume

Exhaust duct



Pro

- ✓ Calculation PN per km
- ✓ Reproducibility of results
- ✓ No modification of brake dyno is required
- ✓ Probe homogeneity
- ✓ Reduction of background particle concentration level
- ✓ Probe homogeneity

Contra


- Special requirements to air ventilations system
- Emissions response is averaged over time and volume

Horiba-AUDI concept

Motivation

Motivation: PMP Protocol for car engine


Cold diluter (PND2) with room temperature air, to minimize particle formation by re-nucleation and particle loss by thermo-pherotic



CVS tunnel, with carbon and HEPA filter

Evaporation tube (ET)
300 to 400 °C, to evaporate volatile particle

Pre-classifier
cut-off: > 2.5 μm



Condensation particle counter (CPC), cut-off: < 23 nm

Heated diluter (PND1) with 191 °C air, to suppress the formation of volatile particle


GRPE Informal Document: GRPE-48-11-Rev.1

Brake dust, first approximation: PMP Protocol confined

GRPE Informal Document: GRPE-48-11-Rev.1

Cold diluter (PND2)

with room temperature air, to minimize particle formation by re-nucleation and particle loss by thermo-pherotic



CVS tunnel, with carbon and HEPA filter

Evaporation tube (ET)
300 to 400 °C, to evaporate volatile particle

Pre-classifier
cut-off: > 2.5 μm

PSP and PTT comprise the sample probe

Carbon and HEPA filters provide particle free and low HC background air

Dilution air in

C HEPA

Humidity and T

CVS Tunnel

PSP

To CFV

SPCS

Particle number concentration

PNC

Size selective inlet: D50 ~20nm

VPR

PND₂ cools and dilutes

@25C

ET: Heated evaporation tube

@350C

Evaporation

PND₁ heats and dilutes

@191C

VPS

PTT

PCF: provides sharp cut-point at 2.5μm

Unstable

Stable

Heated diluter (PND1)
with 191 °C air, to suppress the formation of volatile particle

Condensation particle counter (CPC), cut-off: < 23 nm

Brake dust, first approximation: PMP Protocol confined

Advantages

- Homogeneous mixture of probe
- Good reproducibility and repeatability of results
- Direct comparison to results for engine emissions
- Volatile content of emission will be removed



Disadvantages

- ✓ Particle number is measured for PM2.5 only
- ✓ Emissions response is averaged over time and volume

Testing and validation of Horiba-AUDI concept



Experimental set-up Horiba-AUDI

- Housing for 100% collection of brake emission
- Position of sampling defined according to GRPE-48-11-Rev.1
- Parallel Particle Number and Particle Size Distribution measurements-DMS
- 10 nm Horiba SPCS for PN measurements
- AK Master



Experimental set-up Horiba-AUDI

- Housing for 100% collection of brake emission
- 2 sampling points
 - Inside testing chamber
 - Exhaust duct



Optional sampling point for isokinetic particle mass measurements

Measurement of Particle Number-Horiba Solution for Exhaust Legislation

MEXA-2000SPCS series

Outlines

Models	MEXA-2000SPCS	MEXA-2100SPCS	MEXA-2200SPCS	MEXA-2300SPCS
Conformed standards	UN/ECE Regulation No. 83 (Rev. 3, Amend. 2) UN/ECE draft Regulation No. 49 ^{*1} (ECE/TRANS/WP. 29/GRPE/2010/7), to be updated	—	UN/ECE Regulation No. 83 (Rev. 3, Amend. 2) UN/ECE draft Regulation No. 49 (ECE/TRANS/WP. 29/GRPE/2010/7), to be updated	— ^{*2}
Measuring principle	Laser scattering condensation particle counting (CPC)			
Lower particle size limit	Counting efficiency of 23 nm particles: 50 % ± 12 %, Counting efficiency of 41 nm particles: 90 % or more			
Measuring components and range	Number concentration of solid particles; 0 – 10000 up to 0 – 50000 particles/cm ³ (after internal dilution) ^{*3}			
Sample handling temperature	47 °C ± 5 °C (Dilute sampling)	Maximum permissible temperature (Direct sampling) 350 °C ^{*4}	47 °C ± 5 °C (Dilute sampling)	Maximum permissible temperature (Direct sampling) 350 °C ^{*4}
Diluted sample temperature	Primary diluter (PND1): 191 °C ± 10 °C Evaporation tube (ET): 350 °C ± 10 °C Secondary diluter (PND2): 35 °C or less	Pre-classifier: 47 °C ± 5 °C Primary diluter (PND1): 191 °C ± 10 °C Evaporation tube (ET): 350 °C ± 10 °C Secondary diluter (PND2): 35 °C or less	Primary diluter (PND1): 191 °C ± 10 °C Evaporation tube (ET): 350 °C ± 10 °C Secondary diluter (PND2): 35 °C or less	Pre-classifier: 47 °C ± 5 °C Primary diluter (PND1): 191 °C ± 10 °C Evaporation tube (ET): 350 °C ± 10 °C Secondary diluter (PND2): 35 °C or less
Dilution factors in diluters	Primary diluter (PND1): 10 to 200 ^{*3} Secondary diluter (PND2): 15	Diluter in DSU: 10 Primary diluter (PND1): 10 to 200 ^{*3} Secondary diluter (PND2): 15	Primary diluter (PND1): 10 to 200 ^{*3} Secondary diluter (PND2): 15	Diluter in DSU: 10 Primary diluter (PND1): 10 to 200 ^{*3} Secondary diluter (PND2): 15
PCRF	0.95 < fr(30 nm) / fr(100 nm) < 1.3, 0.95 < fr(50 nm) / fr(100 nm) < 1.2			
Volatile particle removal efficiency	99% or more, for C ₄₀ (30 nm of particle size, and 10000 particles/cm ³ or more)			
Accuracy of dilution factor	Within ± 10 % of nominal dilution factor setting (for VPR total dilution factor of 150 to 3000, gas based)			
Operating environment	Without CLU (standard): Ambient temperature: 5 °C to 30 °C, Ambient humidity: 80 % or less as relative humidity With CLU (optional): Ambient temperature: 5 °C to 45 °C, Ambient humidity: 80 % or less as relative humidity			
Power supply voltage and frequency	200/220/230/240 V AC (±10 %, max. 250 V), 50/60Hz (±1.0 Hz), single phase (to be specified at ordering)			
Power requirements	Main unit: Max. 2.3 kVA Main unit and all optional units: Max. 4.5 kVA	Main unit: Max. 2.5 kVA Main unit and all optional units: Max. 4.4 kVA	Main unit: Max. 2.4 kVA Main unit and all optional units: Max. 4.3 kVA	Main unit: Max. 2.6 kVA Main unit and all optional units: Max. 4.5 kVA
Dimensions (excluding any projections)/Mass				
Main unit (without transfer tube, control unit and optional units)	434(W)×731(D)×600(H) mm Approx. 115 kg	434(W)×845(D)×600(H) mm Approx. 120 kg	434(W)×910(D)×600(H) mm Approx. 140kg	434(W)×910(D)×600(H) mm Approx. 145 kg
Optional units ^{*5}	CYU: Approx. 290(W)×146(D)× 236(H) mm Approx. 4 kg SRU: Approx. 300(W)×550(D)× 450(H) mm Approx. 35 kg CLU: Approx. 570(W)×850(D)×1190(H) mm Approx. 80 kg (for CLU and optional cabinet) DFC: Approx. 464(W)×550(D)× 320(H) mm Approx. 38 kg LCU: Approx. 350(W)×690(D)× 670(H) mm Approx. 35 kg VGU: Approx. 550(W)×300(D)× 450(H) mm Approx. 20 kg			

*1: Only for full flow tunnel.

*2: MEXA-2300SPCS can be used in the measurement method according to the regulation. For detailed information, please contact HORIBA.

*3: Dilution factor of the system should be determined so that the particle concentration after dilution fits into the measuring range.

*4: Allowable range of gas temperature at sample probe inlet depends on the sampling condition, because it is limited as the temperature of diluter in DSU (350 °C or less). For detailed information, please contact HORIBA.

*5: The dimensions depend on customers.



Concentration

Low detection limit up to: 0 #/cm³

Upper detection limit : 3x10⁸#/cm³

Size

Low detection limit : 10-23 nm

Upper detection limit : 2,5µm

Measurement of Particle Mass-Horiba Solution for Exhaust Legislation

DLS-7000 PMP-conform

SPECIFICATIONS

Model:	DLS-7000
Dimensions:	570 (W) x 810 (D) x 1785 (H) mm
Mass:	Approx. 400 kg
Coating:	Munsell 5PB7/1 for the enclosure Munsell 5PB8/1 for the side plates
Power:	200 V to 230 V AC $\pm 10\%$, 50/60 Hz
Power consumption:	3 kVA
Ambient temperature:	5° C to 35° C
Ambient humidity:	less than 80% (relative humidity)
Sampling rate:	25 L/min to 50 L/min
Flow rate sensitivity:	$\pm 5\%$ of full scale
Suction power:	- 53.3 kPa at 50 L/min
Flow meter:	Venturi flow meter
Flow rate control:	PID control
Sample line:	4 lines changeable (Maximum)
Background line:	1 line (Option)



Results – Housing Concept


Objective: avoid the dissipation of emitted particles inside the dynamometer test chamber



housing is sealed carefully
→ direct air flow leads almost all ultra-fine particles to the exhaust duct

Results – Housing Concept

reference sampling point




Without housing: particle losses, single brake applications can be observed
With housing: low and stable particle concentration (NO H13-filter!)


HORIBA

Question: thermal condition of the brake?



Results – Housing Concept




Results – Housing Concept




Verification of sampling concept: Particle size distribution



Without housing



Without housing





Implementation of the housing to sampling chain:

- ❖ Allow to collect all emitted particulates
- ❖ Does not change particle size distribution
- ❖ Increase the number of collected particles for all particle sizes

Testing and Validation of Horiba-AUDI concept



Implementation of Housing: Air Flow effect



- ❖ Horiba-AUDI concept is validated for PN measurements!
- ❖ Application of housing is strongly improved reproducibility $\pm 15\%$ of test results
- ❖ Particle emission depends on air flow velocity and sequence

Definition of measurement range



Definition of measurement range: Influence of sub-23 nm particle



- Appearance of ultra-fine particle depends on wheel speed rather than on brake pressure or temperature
- Ultra-fine particles demonstrate first peak around 13 nm
- Disagreement between DMS and SPCS was observed

Definition of measurement range: Influence of sub-23 nm particle


Aerosol sample-splitter after the exhaust duct → standard SPCS (23 nm) versus prototype SPCS (10 nm)




- ❖ No significant variations of qualitative time history
- ❖ Difference: same order of magnitude but factor varies between 2 and 6
- ❖ Ratio $PN_{\text{sub23}}/PN_{\text{standard}}$ between single brake events is almost stable (around 1,5)
- ❖ Prototype with cut-off D_{50} at 10 nm is used in our research

Particle Number measurements: Electrometer versus CPC-based devices

Comparison of measured particle concentration using Palas particle generator



Comparison of particle concentration measured during brake tests



- ❖ Different factors can affect results of measurements for electrometer based instruments
- ❖ Only CPC based instruments fulfilled exhaust legislation requirements
- ❖ Electrometer-based techniques can be used for indicative measurements only

Finding's

- ❑ Most suitable sampling point for PN was defined
- ❑ Results can be directly compared to data obtained for exhaust measurements
- ❑ Horiba-AUDI set-up provide 100% sampling of Brake Dust Airborne
- ❑ Testing parameters such as air flow, air quality, etc. can affect results of PN measurements
- ❑ By variation of air flow velocity different dilution ration can be applied
- ❑ Particle emission was measured in range $1 \times 10^5 - 10^6$ particle/cm³
- ❑ SPCS particle counter was modified to 10 nm cut-off according special requirements for Brake Dust Emission measurements
- ❑ Reproducibility of results can be achieved only by removing of volatile content
- ❑ Horiba-AUDI set-up provide good reproducibility for particle emission measurements
- ❑ Horiba-AUDI set-up can be used for R&D research on material of brake pads and disks as well as for brake certification
- ❑ Horiba-AUDI set-up can be installed nearly at every brake dynamometer without big modification

Outlook

- ❑ Continue research on definition of sampling point and Evaluation role of probe dilution and sampling velocity
- ❑ Evaluation role of non-brake parameters- velocity of air flow, direction of flow, humidity etc.
- ❑ Comparison of brake pads produced of different materials- ECE, NAO, Ceramic
- ❑ Investigations on composition of brake dust emissions
- ❑ Robin Round at 2-3 Labs
- ❑ Test feasibility of PM for brake airborne measurements
- ❑ Break Wear was reported to be reponsible for mechanical stability of brakes as well as NVH effects-material research on this topic will significantly extend markt capacity from certification to material R&D

Omoshiro-okashiku
Joy and Fun

おもしろい
おかし

眞峰



Thank you

Cảm ơn

감사합니다

ありがとうございました

Dziękuję

धन्यवाद

Grazie

Merci

谢谢

භවතුණකර්ම

நன்றி

Gracias

Obrigado

Σας ευχαριστούμε

Děkuji

Teşekkürler

شكرا

Tack ska ni ha

Danke

Большое спасибо