



# The European Commission's science and knowledge service

Joint Research Centre

## Progress on thermal propagation testing

*Andreas Podias, Akos Kriston, Andreas Pfrang,  
Vanessa Ruiz, Adriano Antonelli, Lois Brett*

December 2019



European  
Commission

# Outline

- 
- **JRC experimental TP activity**

- 
- Initiation tests: update on inductive heating

- 
- First results from short stack tests
  - Next steps: further evaluation and module tests

# JRC experimental TP activity

## Cell & material

### Comparison of initiation techniques

- Trigger energy/ energy release
- Repeatability + ARC, DSC

## Short stack

### Analyse influential factors on the outcome

- Temperature, SOC...
- Cell configuration
- Spark source

## Module

### Evaluate repeatability, reproducibility

- Check proposed test descriptions (also with testing bodies)
- Round robin tests
- Define pass/fail criteria

## Pack, Vehicle

### Verification and finalization of method

- Round robin tests
- Practical aspects
- Define robust evaluation methods (e.g. gas analysis)

Narrow down init. methods

Refine test description

Select equivalent test(s)

# JRC experimental TP activity

## Cell & material

### Comparison of initiation techniques

- Trigger energy/ energy release
- Repeatability + ARC, DSC

## Short stack

### Analyse influential factors on the outcome

- Temperature, SOC...
- Cell configuration-orientation
- ~~Spark source~~
- Cell separation

## Module

### Evaluate repeatability, reproducibility

- Check proposed test descriptions (also with testing bodies)
- Round robin tests
- Define pass/fail criteria

## Pack, Vehicle

### Verification and finalization of method

- Round robin tests
- Practical aspects
- Define robust evaluation methods (e.g. gas analysis)

Narrow down init. methods

Refine test description

Select equivalent test(s)

# Recap of previous findings

- Literature review and JRC workshop showed that the currently proposed description of TR initiation techniques in the GTR might not be fully suitable for TP assessment
- Simulation of thermal runaway showed that the resistance ( $R_{\text{ext}}/R_{\text{int}}$ ) ratio and the surface-to-volume ratio have the highest impact on thermal runaway probability
- Initiation test campaign showed that TRIM method works reliably on different cell types (also nail penetration worked ok, but it was sensitive to boundary conditions)

# Evaluation of methods: if triggering TR is the purpose

Initiation method	Indicators					Scores
	Influence of parameters	Energy insert	Locality	Readiness	Manipulation	
<b>Heating</b>	Low	High	No	Yes	High	2
<b>Steel nail</b>	High	Low	Yes	Yes	High	3
<b>Ceramic nail</b>	High	Low	Yes	Yes	High	3
<b>TRIM method</b>	Low	Low	Yes	Yes	Low	5
<b>Inductive heating</b>	Low	Low	Yes	No	TBC	3

# Outline


- 
- JRC experimental TP activity

- 
- **Initiation tests: update on inductive heating**

- 
- First results from short stack tests
  - Next steps: further evaluation and module tests

# Alternative initiation method: Inductive heating

## Why?



## How?

Alternating electromagnetic field  
generate local current (eddy current)  
which in turn generate heat in any closed  
loop conductors, e.g. Al, Cu, graphite,  
NMC

- Does not require direct contact:  
less manipulation may be needed
- Coil geometry is not limited in  
shape and size



# Pouch cell tests




Single coil  
#4



Double  
(Helmholtz)  
coil  
#5

Initiation → ISC Development → TR



# Preliminary results on single cells

\*The current device was not optimized for short 'on' time, therefore the heating energy is just a rough approximation.

Cell	Power, heating time*	Results
#1, 18650 3.1 Ah	1.2 kW for 2 s: ca. 6.5% of cell's energy, single coil around the cell	TR with fire, $T_{\max}=830^{\circ}\text{C}$ . TR happened during heating. The case opened near the coil.
#2, 18650 3.1 Ah	1.2 kW for 1 s, ca. 3.3% of cell's energy, single coil around the cell	TR with fire, $T_{\max}=734^{\circ}\text{C}$ . TR happened during heating. The case also opened near the coil.
#3, 18650 3.1 Ah	1 kW for 0.5 s, ca. 1.5% of cell's energy, single coil around the cell	TR with fire, $T_{\max}=741^{\circ}\text{C}$ . TR happened several seconds after the heater was switched off. The pouch opened near the coil.
#4, Pouch, 39 Ah	1.2 kW for 2 s, ca. 0.41% of cell's energy. The coil is placed parallel to the surface at the middle of the cell	TR with fire, $T_{\max}=\text{ca. } 400^{\circ}\text{C}$ The pouch opened near the coil.
#5, Pouch, 39 Ah	1.2 kW for 1 s, ca. 0.2% of cell's energy. The cell was placed between the coil.	TR without fire, $T_{\max}=420^{\circ}\text{C}$ The cell ruptured at the side but not under the coil.
#6, Prismatic, hard Al case, 96 Ah	2.4 kW for 3 s, ca. 0.78% of cell's energy	TR with fire, $T_{\max}=550^{\circ}\text{C}$ . The case opened near the coil.

- Locally damage the cell
- Works fast
- Needs small amount of energy

Video 18650, #3

# Updated results on single cells

Inductive heating conditions were reproduced (cell replaced by stainless steel screw) and current/voltage and heating duration were measured.

Cell	Nominal power, heating time	Estimated power, heating time	Estimated inserted energy / electrical energy content
#1, 18650 3.1 Ah	1.2 kW for 2 s	max. 1.2 kW for ca. <b>3.1 s</b>	ca. 6.9 %
#2, 18650 3.1 Ah	1.2 kW for 1 s	max. 1.2 kW for <b>2.2 s</b>	ca. 3.1 %
#3, 18650 3.1 Ah	1 kW for 0.5 s	max. 1 kW for <b>1.6 s</b>	ca. 0.9 %
#4, Pouch, 39 Ah	1.2 kW for 2 s	max. 1.2 kW for <b>3.1 s</b>	ca. 0.5 %
#5, Pouch, 39 Ah	1.2 kW for 1 s	max. 1.2 kW for <b>2.2 s</b>	ca. 0.25 %
#6, Prismatic, hard Al case, 96 Ah	2.4 kW for 3 s	max. 2.4 kW for <b>4.2 s</b>	ca. 0.7 %

# Conclusion remains valid

- Inductive heating tests showed, that minimal energy input ( $\sim 1\%$ ) was needed to initiate TR. Local initiation is sufficient to trigger TR

# Outline

- 
- JRC experimental TP activity

- 
- Initiation tests: update on inductive heating

- 
- **First results from short stack tests**
  - **Next steps: further evaluation and module tests**

# Draft short stack test matrix

Initiation method	Automotive 39 Ah pouch cells/stacks/modules			
Test type	Cell initiation	Short stack	Module	Total
Heating?		?		
Ceramic nail				
TRIM method				
Total	5	16	2	23

# Short stack test matrix

Initiation method	Automotive 40 Ah pouch cells/stacks/modules			
	Test type	2 cell stack	5 cell stack	Module
Ceramic nail	-	4	-	4
TRIM method	3	12	2	17
<b>Total</b>	<b>3</b>	<b>16</b>	<b>2</b>	<b>21</b>

# Short stack test matrix: progress

Initiation method	Automotive 40 Ah pouch cells/stacks/modules			
	Test type	2 cell stack	5 cell stack	Module
Ceramic nail	-	4	-	4
TRIM method	3	12	2	17
<b>Total</b>	<b>3</b>	<b>16</b>	<b>2</b>	<b>21</b>

Executed

To be executed



# Initiation test campaign: severity

Test	Low severity	High severity	Comment
Steel nail Ceramic nail	Stop nail at a certain voltage drop (mV)	Penetrate until event	Every cell has different voltage drop
Heating	1 heater	2 heaters	The heating power per heater kept constant. Increasing the energy intake
TRIM	Lowest possible e.g. 250 °C for pouch	600 °C until event	Varying soaking temperature and time

# Testing matrix 5 cell stack tests

Initiation Method	Insulation material	
	None	HKO Defensor-Flex <sup>®</sup> ML (multilayer) 17
TRIM	6	6
Ceramic nail	2	2
Total	8	8

Compression of ML17 from 5 mm to 4 mm thickness by applying 1 kN (further compression possible with larger force)


Different orientation of the stack (vertical or horizontal cells) will also be assessed for TRIM

# Evaluation of short stack tests

Preparatory steps – same compression force (1 kN)  
for all tests

Ceramic nail penetration // Fast heating (TRIM)

2-cell short stacks // 5-cell short stacks



(A)



(B)




# Evaluation of short stack tests

Ceramic nail penetration tests // 5-cell stack

## Graphite/Ni rich NMC pouch cells



Capacity	Specific energy at C/3	Volumetric energy density at C/3
40 Ah	150 Wh/kg	230 Wh/l



# Evaluation of short stack tests

Ceramic nail penetration test conditions and location of thermocouples // 5-cell stack without ML


Nail diameter	Circular cone tip angle	Penetration Velocity	SoC
3mm	30°	0.1 mm/s	100%




# Evaluation of short stack tests

Ceramic nail penetration tests // 5-cell stack without ML

JRC Test #4 / 5-cell stack / nail / without material  
Total TR time from cell#1 to cell #5 111 s





JRC Test #4 / 5-cell stack / nail / without material  
Total TR time from cell#1 to cell #5 111 s




# Evaluation of short stack tests

## Ceramic nail penetration tests // 5-cell stack with ML



# Evaluation of short stack tests (preliminary)






- Progression of TP seems to be predictable for both cases
- ML slowed down TP (by a factor of about 4)



# Evaluation of short stack tests

Fast heating (TRIM) test conditions and location of thermocouples // 5-cell stack without ML

Target temperature	Temperature increase rate	SoC
600°C	50°C/s	100%




# Evaluation of short stack tests

Fast heating (TRIM) // 5-cell stack // preparations



# Evaluation of short stack tests

## Fast heating (TRIM)




# Evaluation of short stack tests

## Fast heating (TRIM)


5-cell short stack/Fast heating (600oC; 50oC/s until event)

Without ML



5 minutes

With ML



15 minutes

# Evaluation of short stack tests

Still on-going

# Evaluation of short stack tests

## Preliminary findings

- Initiation by TRIM and ceramic nail penetration works ok
  - **Criterion for stopping initiation ('until event') to be evaluated further**
- Propagation times
  - **Rather consistent for identical conditions**
  - **Delay of propagation by addition of multi-layer material**
  - **Statistical analysis will be performed**
- Time/criteria for defining/determining thermal runaway to be investigated further

# Further steps

- Improve understanding of the different failure mechanisms caused by different methods (e.g. local and global effects)
  - Further complementary experimental work at material level (e.g. thermal analysis) and at cell level (ARC)
  - Evaluation of stack/module-level TP testing campaign
- Further collaboration with Canada on TRIM method**
- Proceed with pack and vehicle level tests

*Regular discussions with other parties are appreciated*



# Acknowledgement

# *BATTEST group*

Franco Di Persio

Ricardo Da Costa Barata

Denis Dams

Lois Brett

Natalia Lebedeva

Emilio Napolitano


Ibtissam Adanouj

Akos Kriston

Andreas Pfrang

Marek Bielewski

Vanesa Ruiz



Andreas Podias, Adriano Antonelli,  
Rene van der Aat (not shown in  
photo)

Special thanks:

For abuse test execution to ZSW  
Harry Döring, Michael Wörz, Jan Endlicher,  
Sven Baum

For provision of HKO Defensor-Flex® ML 17  
[ulrich.stude@saint-gobain.com](mailto:ulrich.stude@saint-gobain.com),  
[carsten.stoeckmann@saint-gobain.com](mailto:carsten.stoeckmann@saint-gobain.com),  
[steffen.mielke@hko.de](mailto:steffen.mielke@hko.de)



# Relevant references



V. Ruiz, A. Pfrang, JRC exploratory research: Safer Li-ion batteries by preventing thermal propagation, Workshop report, ISBN 978-92-79-96399-5, Publications Office of the European Union, <https://ec.europa.eu/jrc/en/publication/jrc-exploratory-research-safer-li-ion-batteries-preventing-thermal-propagation>

OPEN  
ACCESS

A. Kriston, A. Antonelli, A. Kersys, S. Ripplinger, S. Holmstrom, S. Trischler; H. Döring, A. Pfrang, Initiation of thermal runaway in Lithium-ion cells by inductive heating, submitted to Journal of Power Sources

OPEN  
ACCESS

A. Kriston, I. Adanouj, V. Ruiz, A. Pfrang, Quantification and simulation of thermal decomposition reactions of Li-ion battery materials by simultaneous thermal analysis coupled with gas analysis, Journal of Power Sources 435 (2019), 226774

Project website <https://ec.europa.eu/jrc/en/research-facility/battery-energy-storage-testing-safe-electric-transport>

360° view of the battery testing laboratory at JRC <https://visitors-centre.jrc.ec.europa.eu/virtual-tour/batterytesting/en/>

Movie about battery testing at JRC <https://www.youtube.com/watch?v=6u2Gjudcas>



# Stay in touch



EU Science Hub: [ec.europa.eu/jrc](https://ec.europa.eu/jrc)



Twitter: [@EU\\_ScienceHub](https://twitter.com/EU_ScienceHub)



Facebook: [EU Science Hub - Joint Research Centre](https://www.facebook.com/EU_Science_Hub_-_Joint_Research_Centre)




LinkedIn: [Joint Research Centre](https://www.linkedin.com/company/joint-research-centre)




YouTube: [EU Science Hub](https://www.youtube.com/EU_Science_Hub)

Back up slides



## Ni-rich NMC/graphite 40Ah pouch cells



# Evaluation of short stack tests

## Ceramic nail penetration tests // 5-cell stack with ML



(A)  $t=100$  s - cell #1 in TR; first instance of white smoke appearance (nail penetrates from the right hand side)



(B)  $t=105$  s - cell #1 in TR; just after grey smoke and sparks appeared



(C)  $t=113$  s - cell #1 in TR; start of fire

$t = 0$  s corresponds to start of nail motion (nail might not touch at start)