


IGPG SG2 – Accelerated Wiper Testing

June 2013 SG2 meeting update






SG2 TARGET:

- ✓ Define principle test setup/test machine
- ✓ Define procedure / test protocol
- Propose an evaluation methodology
- ☐ Check Repeatability and reproducibility
- ☐ Correlate with Subgroup I onroad results







MEETING HAD IN DARMSTADT W48/2012

- ☐ Feed back on preliminary test result carried on some equipment
- □ Reviewed Methodology & Equipment based on questionnaire feed back from Bayer, Bosch, BYK, Evonik, Momentive, PSA, Renault, SABIC, Valeo
- □ Defined wiper lab equipment / wiper test methodology / main protocol /evaluation methodology, with identification of main "extreme condition" protocols
- ☐ Reviewed planning from 11/12 to 04/13



Reviewed Methodology & Equipment based on questionnaire feed back from Bayer, Bosch, BYK, Evonik, Momentive, PSA, Renault, SABIC, Valeo

Questionnaire feed back on below main topics:

- Available test equipments
- Wiper blades
- Mud/Mixture
- ☐ Protocols (Load, velocity, test cycle, flow rate, samples...)
- Evaluation methodology
- ☐ Comparison with real data






IGPG-SG2 ACCELERATED WIPER TESTING – PROCESS

- ☐ Each sample was measured in 9-12 locations depending on the size of the sample
- Analysis Tools were percent change in haze and percent change in clarity
- Samples were measured on both exposed and unexposed sides
- ☐ Five different test methods were used
 - A. Wet with Bath for 25,000 cycles. Tested by Bayer, Bosch, Evonik, and Momentive.
 - B. Wet with Slurry Flow for 25,000 cycles. Tested by SABIC
 - C. Dry for 1,000 cycles. Tested by Bayer, Bosch, Evonik, and Momentive.
 - D. Continuous Protocol: 10 dry cycles, 20 wet cycles, 6 seconds off, repeated up to 25,000 cycles. Tested by SABIC
 - E. Wet with Bath for 25,000 cycles then dry for 1,000 cycles (A + C). Tested by Bayer, Bosch, Evonik, and Momentive



IGPG-SG2 ACCELERATED WIPER TESTING - RESULTS

- ☐ Analysis based on Delta Haze on exposed side of sample.
- □Without taking interactions into account, including all test methods and labs, there appears to be a visible difference between sample types.



NOTE: Wet coated PC samples must be retested due to an expected error in coating application of original samples.



IGPG-SG2 ACCELERATED WIPER TESTING - RESULTS

Results per test method:


- A.One of the test labs showed high variability in comparison to the other labs. Retesting is in progress.
- B. No statistical difference was between the materials and not noticeable using delta haze. All mean results were less than 1%.
- C.There is a statistical difference between materials, but no statistical difference between the laboratories (possibly due to the variability in the test and samples). Variability is the same for all labs used.
- D. Results appear most consistent when reviewing the standard deviations per material.
- E. Not enough samples were tested to show the repeatability or reproducibility of this method.



IGPG-SG2 ACCELERATED WIPER TESTING - CONCLUSIONS

- ☐ There is high variation in all tests except for Test D.
- ☐ There is low variation in Test A only specific to one test lab.
- □ In order to really understand if the values are real, we need to increase the sample size to possibly 10. 3 samples may not enough based on the variation that is present in these tests.
- ☐ Using another analysis tool may provide better insight to the difference in samples, labs and protocols that haze cannot provide.

Sample Variation / Standard Deviation (including all samples tested per protocol and lab)





IGPG-SG2 ACCELERATED WIPER TESTING – PATH FORWARD


As agreed based on the results we will perform a second quick round test as following:

Procedure A Sample PC Wet Coated Laboratory Bayer, Bosch, Evonik, Momentive Procedure A_Low (test at lower speed) Sample PC Wet Coated Laboratory Bayer, Bosch, Evonik, Momentive

Procedure **D** Sample PC Wet Coated Laboratory SABIC
Procedure **D_Low** (test at lower speed) Sample PC Wet Coated Laboratory SABIC

Will be tested N° 3 sample for each protocol/laboratory.







DISCLAIMER

DISCLAIMER: THE MATERIALS, PRODUCTS AND SERVICES OF SABIC INNOVATIVE PLASTICS HOLDING B.V. ITS SUBSIDIARIES AND AFFILIATES ("SELLER"), ARE SOLD SUBJECT TO SELLER'S STANDARD CONDITIONS OF SALE, WHICH CAN BE FOUND AT http://www.sabic-ip.com AND ARE AVAILABLE UPON REQUEST. ALTHOUGH ANY INFORMATION OR RECOMMENDATION CONTAINED HEREIN IS GIVEN IN GOOD FAITH, SELLER MAKES NO WARRANTY OR GUARANTEE, EXPRESS OR IMPLIED, (i) THAT THE RESULTS DESCRIBED HEREIN WILL BE OBTAINED UNDER END-USE CONDITIONS, OR (ii) AS TO THE EFFECTIVENESS OR SAFETY OF ANY DESIGN INCORPORATING SELLER'S PRODUCTS, SERVICES OR RECOMMENDATIONS. EXCEPT AS PROVIDED IN SELLER'S STANDARD CONDITIONS OF SALE, SELLER SHALL NOT BE RESPONSIBLE FOR ANY LOSS RESULTING FROM ANY USE OF ITS PRODUCTS OR SERVICES DESCRIBED HEREIN. Each user is responsible for making its own determination as to the suitability of Seller's products, services or recommendations for the user's particular use through appropriate end-use testing and analysis. Nothing in any document or oral statement shall be deemed to alter or waive any provision of Seller's Standard Conditions of Sale or this Disclaimer, unless it is specifically agreed to in a writing signed by Seller. No statement by Seller concerning a possible use of any product, service or design is intended, or should be construed, to grant any license under any patent or other intellectual property right of Seller or as a recommendation for the use of such product, service or design in a manner that infringes any patent or other intellectual property right.

Brands marked with ™ are trademarks of SABIC. © 2012 Saudi Basic Industries Corporation (SABIC). All Rights Reserved.

^{*} Exatec is a trademark of Exatec, LLC.